



Driver Upgrade Instructions

Table of Content

Installing updated drivers in Microsoft Windows 7 _____	2
<i>Install Procedure for Network Printing from Windows 7</i> _____	<i>2</i>
<i>Installing Software for Local Printing for Windows 7</i> _____	<i>2</i>
<i>Uninstall Procedure for Windows 7</i> _____	<i>3</i>



Installing updated drivers in Microsoft Windows 7

Install Procedure for Network Printing from Windows 7

1. Download the latest drivers and utilities from <http://www.support.xerox.com/>.
2. The downloaded file is in the .zip format and will need to be extracted to a folder on the client.
3. See <http://windows.microsoft.com/en-us/windows7/Install-a-printer> for generic instructions for driver install on Windows 7.
4. Complete the installation. When prompted, print a test page to ensure that the printer driver is installed properly.

Installing Software for Local Printing for Windows 7

A local printer is a printer directly attached to your computer using the printer cable supplied with your printer, such as a USB or parallel cable.

1. Download the latest drivers and utilities from <http://www.support.xerox.com/>.
2. The downloaded file is in the .zip format and will need to be extracted to a folder on the client.
3. Connect your computer to your Xerox printer with USB cable. Turn on printer.

Note:

- *Windows Update will install the USB port for the printer and search for the print driver. Print driver installation will fail (expected behavior).*
4. Use the Add Printer Wizard to install the print driver, selecting the USB port and browsing to the location of the files extracted in step 2 above.

You have now completed all steps in performing a Windows Driver upgrade.



Uninstall Procedure for Windows 7

Xerox printer wizard uninstall procedure:

1. **[Select Start, All Programs, Xerox {Printer Model}, Maintenance].**

Note: If the Maintenance option is not available the printer drivers will need to be manually uninstalled in the Windows Printers folder. See Windows driver uninstall steps below.

2. Select **Remove** and click **[Next]**.
3. Check all components in the **Select Components** window and click **[Next]**.
4. Confirm that you want to remove the selected programs by clicking **[Yes]** on the pop-up window.
5. Click **[Finish]** once the uninstall procedure is complete.

Microsoft Windows printer driver uninstall procedure:

Note: If the Xerox Printer Wizard Procedure (above) was not available or did not complete successfully the following steps must be followed for the printer drivers to be uninstalled successfully:

1. **[Select Start, Control Panel, System and Security, Administrative Tools, Print Management].**
2. Select **[All Printers]** on the left menu.
3. Delete all the printer objects associated with the printer driver you want to uninstall.
4. Select **[All Drivers]** on the left menu.
5. Highlight the driver you would like to uninstall and click **[Action, Remove Driver Package]** to uninstall the driver files and any related registry entries.

Note: If the driver is not present then it has already be uninstalled from Windows.

6. Confirm that you want to remove the selected Drive Package by clicking **[Delete]** on the pop-up window.