








Xerox® Phaser® 6500


Repacking Instructions • Instructions d'emballage • Istruzioni per l'imballaggio • Hinweise für das Verpacken
 Instrucciones de reembalaje • Instruções para reembalagem • Instructies voor opnieuw inpakken
 Instruktioner för ompaketering • Instruksjoner for pakking • Instruktioner om genindpakning • Instruksjoner for pakking
 Instruktioner om genindpakning akkausohjeet • Инструкции по повторной упаковке • Pokyny pro opětovné zabalení
 Instrukcje przepakowywania • Csomagolási útmutató • Yeniden Paketleme Yönergeleri • Οδηγίες επιστροφής προϊόντος

 See the instructional video at
www.xerox.com/office/




7


7




8



9




10




11





12



13



14



15

