

Fig. 1 **Top left cover**Gently open the top left cover while lifting up the release lever.



If the edge of the jammed paper can be reached at the output tray, pull the jammed paper in the direction of the feed-out area.




Fig. 3

If you cannot remove the jammed paper, access the fuser area, lift up the green lever and remove the jammed paper.



Fig. 4 **Duplex Module Cover**Open the tray 5 (Bypass) and gently open the duplex module cover.



Fig. 5
Remove the jammed paper.



Fig. 6
Tray 5 (Bypass)
Inspect the inside (paper

Inspect the inside (paper feed entrance) of Tray 5 (Bypass), and remove any jammed paper.




Fig. 7 **Duplex Module Cover**Remove the jammed paper.



Fig. 8 **Bottom left cover**Remove the jammed paper.




Fig. 9

Paper Tray 1 to 4

Remove the jammed paper.

## **Quick Start Guide**

Removing Paper Jam



WorkCentre Pro C2128/C2636/C3545

