


Margins and print area

When the printer places an image on paper, the image (print area) is a bit smaller than the paper size. You may need to adjust the page margins in your application software to match the print area.

This illustration shows the page dimensions, margins, and the largest print areas for all sizes of paper and transparency supported on this printer. The names in parentheses are the choices that appear in the driver.

1. A (Letter)
2. Metric letter (A4)
3. B (Tabloid)
4. Metric tabloid (A3)
5. WB (Tabloid Extra)



8849-21A

The standard tray supplied with the printer accommodates B, A3, and WB sizes. The tray for A and A4 must be ordered separately.