

Printing the front panel menu map

The front panel menu map provides a convenient navigation aid for quickly determining the location of menu items. The menu map can be printed from the front panel.

1. While the **Ready** message is displayed, press the **Menu** button. The printer displays the first item in the menu:

```
Help Pages
<----- > Menu
```

2. Press the **Menu** button to enter the Help Pages menu. The following message appears:

```
Test Print
<----- > Print
```

3. Press the left arrow button (<---) until the display reads:

```
Menu Map
<----- > Print
```

4. Press the **Print** button to print the menu map page.
5. Return to the top level of the menu by pressing the **Exit** button until the printer displays the **Ready** message.