

Release Notes



Phaser 3010

Firmware Release version SG1_XC_2.02

Release Date: January 2013

Software Release Details

Component	Version
Firmware	SG1_XC_2.02

Purpose

This firmware release contains the following fixes:

- Support for European Union Lot 6 energy requirements on 220V units manufactured after January 1, 2013
- The Paper Size and Paper Type no longer needs to be set in the Printer Setting Utility. The printer will use the Paper Size and Paper Type set in the driver when a job is sent

I. Installation Notes

The Firmware Release is located at the following location:


<http://www.support.xerox.com/go/getfile.asp?objid=122817&EULA=28&Xtype=download&uType=>

Firmware Upgrade Process


Windows Operating Systems

Caution: Do Not Reboot or Turn Off the printer during the firmware update process. The printer will automatically reboot when finished downloading the firmware.


1. Make sure the printer is powered on and connected over USB.
2. On the printer, print a System Settings Report to document the current printer settings.
3. On the computer, double-click on the **xrfdl_SFP.exe** icon located in the firmware folder.
4. The **Xerox Printer Firmware Update Tool** window listing the firmware components is displayed. Press the **Next** button.



5. Check the box for the printer you want to update, and press the **Next** button to send the firmware update to your printer.



- The following message will be displayed:



- The printer's green LED light will blink while it is receiving the firmware update.
 - The printer will reboot after the firmware is updated. Print a System Settings Report to verify the updated firmware version.
6. After the firmware upgrade is complete, click the **Finish** button to exit the firmware upgrade tool.

