

*Phantom Jobs*  
*X12 v1.5*

**Problems Addressed:**

When Fiery X12 is Rebooted/ Restarted, jobs that have previously printed will begin to print again.

**Solution:**

Download the 1-8FMZ6.ps to the Fiery Server.

This update consists of the following file:

File Name	File Size
1-8FMZ6.ps	390 KB

**Installation Instructions:**

1. Download 1-8FMZ6.ps file via the Fiery Downloader or Web Downloader to the Print queue or if using the import function of CWS 4.x to import to the Hold queue, then print.
2. In Command Workstation/Spooler (web), verify that 1-8FMZ6.ps is in the printed queue.
3. Wait 60 seconds.
4. Reboot the Fiery server from the Fiery Control Panel.
5. After the server has restarted, please wait until it goes to idle and print a Configuration Page to verify that the file has been received. The Update Information should contain the patch number 1-8FMZ6.ps.