

Kit Installation Instructions

EPM SPAR Team

Product(s):	EX4112/4127	Date:	08/08
Title:	1-URBZT Installation instructions	Page:	1 of 1

Purpose

This software kit provides an EX4112/4127 software update in response to an EX4112/4127 SPAR. Refer to the included customer letter for more information.

In the event of an EX4112/4127 system reinstall this software should be reapplied.

Kit Contents

Qty.	Description
1	Kit Installation Instructions
1	Customer Letter
1	1-URBZT.exe file

Prerequisites

- Previous working knowledge with the EX4112/4127
- The EX4112/4127 must be at version 1.0 prior to performing this install. This software is supplemental to the 1.0 launch software.

NOTE: This patch is for v1.0 ONLY, if you have upgraded to v2.0, do not install this patch.

Installation Instructions

NOTE: This software may be installed by the customer following these instructions.

Install the EX4112/4127 1-URBZT patch:

- ___ 1. Copy the 1-URBZT.zip file to a PC
 - ___ a. Unzip the file
 - ___ b. Open the 1-URBZT folder
- ___ 2. Install the 1-URBZT patch
 - ___ a. Double click on the 1-URBZT.exe file
 - ___ b. At the Fiery Patch Download window, click [Next]
 - ___ c. At the License Agreement window, click [Accept]
 - ___ d. At the Fiery Logon window, type the Fiery administrator login password in the Password field

NOTE: Do NOT change the User field; that value must be admin.

- ___ e. In the Hostname field, type in the IP address or hostname of the EX4112/4127 and select [Connect]
- ___ f. At the Server Information window, select [Download]. The patch will be downloaded and installed
- ___ g. At the Processing window, select [Next], wait for approximately one (1) minute
- ___ h. On the final window, select [Reboot], then select [Finish]
- ___ i. Once the Command WorkStation is open, select [Server] [Reboot] to reboot the Server again.

NOTE: This patch is exclusive. It must be installed, the Server rebooted, then additional patches may be applied.

- ___ 3. Verify that the patch is installed and wrap-up
 - ___ a. Once the Fiery status says "Idle," select [Server: Print Pages] from the CWS menu and print a configuration page.
 - ___ b. On the "System Update Log" sheet of the configuration pages, ensure that the patch 1-URBZT is listed
 - ___ c. At the PC, save the 1-URBZT.zip file in case it is needed in the future and delete the 1-URBZT folder.