

# Release Note

General information	
Issue ID Number	1-E4VH1
Product Name	Fiery on XPE operating system
Issue Date	30 August 2004

1-E4VH1.ps (to enable remote desktop)	2 Kilobytes
1-E4VH1-R.ps (to disable remote desktop)	2 Kilobytes
Relnotes.pdf	

Closed - Patch	

**Installation Steps to Enable Remote Desktop:**

1. Download/Import the patch file “1-E4VH1.ps (to enable remote desktop)” with either Fiery Downloader or Command Workstation to the “Direct” queue.
2. You must wait at least 60 seconds after the patch file downloaded/imported before rebooting the system. This will ensure the patch file is completely processed.
3. The system must be rebooted twice for the patch to be effective using the following steps.
4. Please select “Shut Down” and then “Reboot System” on the Fiery LCD. When the Fiery has come to “Idle”, repeat the steps to reboot the system.
5. Please wait until the Fiery has come to idle after the second reboot to print out the configuration page.

Verify the **Update Info** section.

It should contain the patch number “1-E4VH1 EnableRemoteDesktop”.

**Installation Steps to Disable Remote Desktop:**

6. Download/Import the patch file “1-E4VH1-R.ps (to disable remote desktop)” with either Fiery Downloader or Command Workstation to the “Direct” queue.
7. You must wait at least 60 seconds after the patch file downloaded/imported before rebooting the system. This will ensure the patch file is completely processed.
8. The system must be rebooted twice for the patch to be effective using the following steps.
9. Please select “Shut Down” and then “Reboot System” on the Fiery LCD. When the Fiery has come to “Idle”, repeat the steps to reboot the system.
10. Please wait until the Fiery has come to idle after the second reboot to print out the configuration page.

Verify the **Update Info** section.

It should contain the patch number “1-E4VH1 DisableRemoteDesktop”.

**Known Issues**

NA