**Online**
Indicator lights when data is being received from a client.

**Help**
Accesses additional information.

**Features**
Displays the job features on the screen.

**Language**
Changes text to an alternative language.

**Access**
Use this administrator level feature to change machine default settings, and to setup or modify user accounts.

**Interrupt**
Temporarily stops the current job to allow a priority job to be run.

**Touch Screen**
Displays and selects all available programming features, plus fault clearance procedures and general machine information.

**Clear All**
Resets all the features to their default settings.

**Stop**
Temporarily stops the current job.

**Start**
Starts the job.

**Job Status**
Displays job progress information.

**Clear**
Deletes numeric values or the last digit entered.

**Machine Status**
Displays the current status of the machine.

**Power Saver**
Lights up green and is initiated automatically if the machine is left idle for a specific amount of time.

**Numeric Keypad**
Is used to enter copy quantity or other numeric information.

**Dial Pause**
Enters a pause in a telephone number when transmitting a fax.

Quick Start Guide

**Control Panel**

# WorkCentre Pro C2128/C2636/C3545

XEROX®