

# The Document Company

## XEROX

### DC220/230ST CentreWare® Internet Services Quick Install

The Xerox DC220/230ST contains an embedded Web Server. CentreWare Internet Services contains tools within the Web Page that allow users to check the status of the queue, submit print ready files as print jobs, scan jobs, configure scanning templates, etc.

In addition, after Internet Services is enabled, machine network configuration and setup can be accomplished from the System Administrator's desktop (password required).

#### Before Installation:

Record the following information for use during setup at the DC220/230:

TCP/IP Address: \_\_\_\_\_

Gateway Address: \_\_\_\_\_

Subnet Address: \_\_\_\_\_

Broadcast Address: \_\_\_\_\_

Host Name: \_\_\_\_\_

A minimum configuration of Microsoft Internet Explorer® 4.x or higher, or Netscape Navigator® 3.x or higher should be used. Other browsers may work, but may not produce expected results.

1. Connect the DC220/230 to your network outlet or cable.
2. Enter System Administrator Setups:
  - a) Press the **[Access]** button on the Control Panel.
  - b) Enter the System Administrator password by typing **#22222** (**# key and 22222**) on the keypad and pressing **[Enter]** on the screen.  
**Note:** #22222 is the factory default password and may be changed by your Xerox service representative to suit your needs.
3. Access the TCP/IP Network Setups screen:
  - a) On the screen display, press **[Print Setups]**.
  - b) Press **[Network Setups]**.
  - c) Press **[TCP/IP]**. If TCP/IP has been enabled and configured, skip to step 4.

- d) **IP Address setup (skip this step if using RARP):** Press **[IP Address]**, then press **[Edit]** and use the keyboard on the display screen to enter the static IP address for the DC220/230. This number is assigned by the System Administrator

OR

- d) **RARP setup (skip this step if using a static IP address):** Press **[RARP]**, then press **[Enabled]**.
- e) Press **[Save]**.
- f) Press **[Gateway Address]**, then press **[Edit]** and use the keyboard on the display screen to enter the Gateway address of your network.
- g) Press **[Save]**.
- h) Press **[Subnet Mask]**, then press **[Edit]**, and use the keyboard on the display screen to enter the Subnet Mask for your network (default is 255.255.255.0).
- i) Press **[Save]**.

# The Document Company

## XEROX

### DC220/230ST CentreWare® Internet Services Quick Install

- j)** Press **[Broadcast Address]**, then press **[Edit]** and use the keyboard on the display screen to enter the Broadcast Address of your network.

**Note:** The Broadcast Address is the address where all host bits are set to either zero (0) or one (1).

- k)** Press **[Save]**.
- l)** Press **[Host Name]**, then press **[Edit]** and use the keyboard on the display screen to enter the Host Name you want your DC220/230 to use.
- m)** Press **[Save]**.
- n)** Press **[Save]** on the TCP/IP screen to save all the network settings.
- o)** Press **[Exit]** on the Network Setups screen.

- 4.** Press **[Additional Setups]** in the upper right corner of the screen.

- 5.** Press **[HTTP]**.
- 6.** Enable HTTP:
- a)** Press **[Enablement]**.
- b)** Press **[Enabled]**.

**Note:** The Port Number and the Maximum Number of Connections are predetermined.

- 7.** Press **[Save]**.
- 8.** Press **[Exit]** on the Network Setups screen. The DC220/230 will reboot and print a configuration sheet in approximately 3 minutes.

- 9.** Check the settings on the configuration sheet against those that were entered.
- 10.** At a client workstation on the network, open the Internet Browser.
- 11.** In the URL field, enter `http://` followed by the IP address of your DC220/230. Example: If the IP address is 127.0.0.1, the URL would be `http://127.0.0.1`.

Refer to the CentreWare manual, *Getting Started with Print and Fax Services* for additional information.

Additional information on network installation can be found in the *DC220/230 System Administration Guide*.