



Fiery® EXP6000/EXP5000 Color Server

SERVER & CONTROLLER SOLUTIONS



Utilities

© 2005 Electronics for Imaging, Inc. The information in this publication is covered under *Legal Notices* for this product.

45049053

15 March 2005

CONTENTS

INTRODUCTION	7
Terminology and conventions	8
About this manual	9
About Help	9
Preparing for installation on Windows computers	10
Preparing for installation on Mac OS 9 computers	11
Mac OS Runtime for Java	11
Fonts	12
COMMAND WORKSTATION, WINDOWS EDITION	13
Installing Command WorkStation, Windows Edition	14
Configuring the connection to the Fiery EXP6000/EXP5000	15
Using Command WorkStation, Windows Edition	18
Additional features	19
Align Trays	19
Printing Groups	20
Reorder Jobs	21
Schedule Printing	22
Rush Printing	22
Mixed Media	23
Insert Tab	27
Soft Proofing	29
EFI ImageViewer	29
Troubleshooting	30
Command WorkStation cannot connect to the Fiery EXP6000/EXP5000	30
Command WorkStation does not respond	31

EFI IMPOSE	32
Installing and enabling Impose	33
Installing Impose	33
Installing Adobe Acrobat and Enfocus PitStop	33
Using Impose	35
COMMAND WORKSTATION, MACINTOSH EDITION	36
Installing Command WorkStation, Macintosh Edition	37
Configuring the connection to the Fiery EXP6000/EXP5000	38
Using Command WorkStation, Macintosh Edition	41
Troubleshooting	42
Command WorkStation cannot connect to the Fiery EXP6000/EXP5000	42
Command WorkStation does not respond	43
FIERY DOWNLOADER	44
Installing Downloader	45
Configuring the connection to the Fiery EXP6000/EXP5000	46
Using Downloader	49
Viewing print status	49
Downloading files and printer fonts	51
Managing printer fonts	55
EFI HOT FOLDERS	58
Installing Hot Folders	59
Using Hot Folders	60

FIERY WEBTOOLS	61
Setting up WebTools	62
Accessing the WebTools home page	63
Using WebTools	64
Status	64
WebLink	64
WebSetup	65
WebDownloader	65
Installer	65
Software Updates	66
INDEX	67

INTRODUCTION

The Fiery EXP6000/EXP5000 Color Server media pack includes a set of software utilities that allow you to manage the Fiery EXP6000/EXP5000 Color Server, as well as the print workflow and content of jobs on the Fiery EXP6000/EXP5000 Color Server.

This manual provides an overview of how to install, configure, and use the following Fiery EXP6000/EXP5000 utilities:

- EFI Command WorkStation, Windows Edition
- EFI Impose
- Command WorkStation LE (also known as Command WorkStation, Macintosh Edition)
- Fiery Downloader
- EFI Hot Folders
- VDP Resource Manager
- Fiery WebTools

Terminology and conventions

This manual uses the following terminology and conventions.

Term or convention	Refers to
Aero	Fiery EXP6000/EXP5000 (in illustrations and examples)
Digital press	DocuColor 6060/5252/2060/2045
Fiery EXP6000/EXP5000	Fiery EXP6000/EXP5000 Color Server
Titles in <i>italics</i>	Other books in this documentation set
Windows	Microsoft Windows 98, Windows Me, Windows NT 4.0, Windows 2000, Windows XP, Windows Server 2003
	Topics for which additional information is available by starting Help in the software
	Tips and information
	Important information
	Important information about issues that can result in physical harm to you or others

About this manual

This manual covers the following topics:

- Command WorkStation, Windows Edition: Monitoring and managing the print workflow of jobs on the Fiery EXP6000/EXP5000 (Windows only).
- Impose: Applying imposition layouts to jobs for custom printing, binding, and cutting purposes (Windows only).
- Command WorkStation, Macintosh Edition: Monitoring and managing the print workflow of jobs on the Fiery EXP6000/EXP5000 (Mac OS X only).
- Downloader: Transferring job files and fonts from your computer to the Fiery EXP6000/EXP5000.
- Hot Folders: Storing and reusing frequently used print options when printing PostScript and PDF files on the Fiery EXP6000/EXP5000 (Windows only).
- VDP Resource Manager: Finding and deleting global objects used in variable data printing.
- WebTools: Managing your Fiery EXP6000/EXP5000 remotely from the Internet or your company's intranet.



For information about installing, configuring, and using EFI Fiery ColorWise Pro Tools, see *Color Printing*.



About Help

Detailed instructions about using most Fiery EXP6000/EXP5000 utilities are provided in Help. Wherever appropriate, this manual refers you to Help for additional information and explains how to access the Help for each utility.

Preparing for installation on Windows computers

Before installing Fiery EXP6000/EXP5000 software on a Windows computer, be sure to complete the following:

- To use Command WorkStation, ColorWise Pro Tools, or WebTools on a Windows computer, install the Sun Java file, Java Runtime Environment (JRE), provided in the Common Utilities folder on the User Software CD. If the Sun Java file is not installed, you are prompted to install it before you proceed. For more information about installing the file, see “To install Sun Java JRE on your computer” on page 10.
- To install the Fiery EXP6000/EXP5000 software, you must have Service Pack 4 installed on a Windows 2000 computer, and Service Pack 1 installed on a Windows XP computer. If not, a warning message alerts you to install the Service Pack.

TO INSTALL SUN JAVA JRE ON YOUR COMPUTER

- 1 **Open the Common Utilities folder on the User Software CD and click the sj141_02.exe installer icon. Proceed to [step 2](#).**

If you started to install Fiery EXP6000/EXP5000 software without installing Sun Java, a dialog box prompts you to install Sun Java JRE. Click OK to proceed.

- 2 **Click Yes in the License Agreement dialog box.**
- 3 **Select Typical for Setup Type and click Next.**
- 4 **When installation of the JRE file is complete, click Finish and follow the on-screen instructions for installing the Fiery EXP6000/EXP5000 software.**

After installation of Sun Java JRE, a Java Web Start shortcut is created on your computer desktop. This is not intended for use with Fiery EXP6000/EXP5000 software. You may delete the shortcut.

Preparing for installation on Mac OS 9 computers

Before installing Fiery EXP6000/EXP5000 utilities on a Mac OS 9 computer, you must install Mac OS Runtime for Java (MRJ) and screen and printer fonts.

Mac OS Runtime for Java

If you do not have the appropriate MRJ installed, the installer automatically installs MRJ from the User Software CD. To run the installer manually, see the following procedure.

NOTE: MRJ v2.2.5 (the recommended version) is provided on the User Software CD.

TO INSTALL MAC OS RUNTIME FOR JAVA

- 1 **Open the OS9:MRJ folder on the User Software CD and double-click Installer.**
- 2 **Read the Apple Computer, Inc. License Agreement and click Agree to install the software.**
- 3 **Click Install.**

The required MRJ files are installed.

- 4 **Click Quit.**

TO UNINSTALL MAC OS RUNTIME FOR JAVA SOFTWARE

- 1 **Locate the System Folder on your hard disk.**
- 2 **Inside the Extensions folder, locate the MRJ Libraries file and remove the file or move it to another folder.**

NOTE: If you find the “MRJ Enabler” file under Extensions, remove it or move it to another folder.

- 3 **Locate the Apple Extras folder inside the Applications folder on your hard disk.**
- 4 **Inside the Apple Extras folder, locate the Mac OS Runtime Java file, and remove the file or move it to another folder.**
- 5 **Restart your computer.**

Fonts

The Fonts installer on the User Software CD includes screen and printer fonts that correspond to the 136 built-in PostScript printer fonts on the Fiery EXP6000/EXP5000. The Font installer copies both types of fonts to the System Folder:Fonts folder on the hard disk of your Mac OS 9 computer. To be available to applications, the screen fonts must remain in the System Folder:Fonts folder. You can copy the printer fonts to a folder of your choice.

NOTE: In the System Folder:Fonts folder, when displayed by Kind, screen fonts appear as type “Font Suitcase” and PostScript printer fonts appear as type “PostScript font”.

TO INSTALL SCREEN AND PRINTER FONTS

- 1 Insert the User Software CD into the CD-ROM drive of the Mac OS computer.**
- 2 Open the OS9 folder.**
- 3 Double-click the Fonts icon to start the Fonts installer.**
- 4 Follow the on-screen instructions to install the fonts. After the installation is complete, restart your computer.**

By default, the fonts are installed to the System Folder:Fonts folder on your hard disk.

You must quit and restart any open applications before the newly installed screen fonts are available.

COMMAND WORKSTATION, WINDOWS EDITION

Command WorkStation, Windows Edition allows Fiery EXP6000/EXP5000 operators (or users with Operator or Administrator privileges) to monitor and manage the print workflow of jobs on the Fiery EXP6000/EXP5000. Command WorkStation, Windows Edition allows you to do the following:

- View the print status of jobs on the Fiery EXP6000/EXP5000.
- Hold, process, and print jobs.
- Override user-assigned print option settings.
- Preview the page content of a job.
- Reorder pages in a job and combine pages from different jobs.
- Create and use EFI Fiery FreeForm master files for variable data printing.
- Archive job files.
- View job logs of recent print activity.

Installing Command WorkStation, Windows Edition

Install Command WorkStation, Windows Edition on a Microsoft Windows computer that has a network connection to the Fiery EXP6000/EXP5000. For a complete list of system requirements, see *Welcome*.

The installer for Command WorkStation, Windows Edition is provided on the User Software CD. In addition to the Command WorkStation software, the installer installs the Java files required to use Fiery Setup from Command WorkStation. For information about using Fiery Setup, see *Configuration and Setup*.



Before you install the utility, be sure to read the guidelines described in “[Preparing for installation on Windows computers](#)” on page 10.

TO INSTALL COMMAND WORKSTATION, WINDOWS EDITION

- 1 **Insert the User Software CD into the CD-ROM drive of the Windows computer.**
- 2 **Open the EFI Command WorkStation folder.**
- 3 **Double-click the setup.exe icon.**
- 4 **Follow the on-screen instructions to complete installation.**

Configuring the connection to the Fiery EXP6000/EXP5000

The first time you start Command WorkStation, you are prompted to configure the connection to the Fiery EXP6000/EXP5000.

You can also edit the configuration whenever there is any change to your Fiery EXP6000/EXP5000 server or network, such as a changed server name or IP address. If you change Fiery EXP6000/EXP5000 Setup information, do so before you reconfigure the connection.

BEFORE YOU BEGIN

- **Print the Fiery EXP6000/EXP5000 Configuration page.**

For instructions about printing the Configuration page, see *Configuration and Setup*.

This page contains information you need when configuring the connection, such as the IP address of the Fiery EXP6000/EXP5000. For TCP/IP installations, you can use the DNS name instead of the IP address. Make sure the Fiery EXP6000/EXP5000 is already registered in a Domain Name Server (DNS) on your network. For more information, see the documentation that accompanies your network system.

TO CONFIGURE THE CONNECTION FOR COMMAND WORKSTATION, WINDOWS EDITION

- 1 **Choose Start > Programs > Fiery > Command WorkStation to start the utility.**

The Available Servers dialog box appears, displaying all servers found in the local subnet.



- 2 If no Fiery EXP6000/EXP5000 servers were found, click the Manual tab to search by DNS name or IP address. Click Add to add the server to the Available Servers list.




- 3 Click the Auto Search tab, and then click Advanced to search by a range of IP addresses or by the IP address and subnet mask.

All available servers appear in the Available Servers list.

- 4 Select the Fiery EXP6000/EXP5000 server that you want to use and click Add.

The selected Fiery EXP6000/EXP5000 is added to the Login Server window.



5 Click the server name.

The Login dialog box appears.



6 Select Administrator, Operator, or Guest and click Log In.

7 Type the password when prompted.

For information about the default Administrator password for the Fiery EXP6000/EXP5000, see *Configuration and Setup*.

Command WorkStation is now connected to the Fiery EXP6000/EXP5000.

TO MODIFY THE CONFIGURATION FOR COMMAND WORKSTATION, WINDOWS EDITION

1 Start Command WorkStation.

The Login Server window appears.

2 Select the Fiery EXP6000/EXP5000 server for which you want to modify the configuration, and click Remove.

3 Repeat “To configure the connection for Command WorkStation, Windows Edition” on page 15.

Using Command WorkStation, Windows Edition

After you install and configure Command WorkStation, you can begin using it to monitor and manage jobs on the Fiery EXP6000/EXP5000.



For complete instructions about using the standard Command WorkStation features, see Command WorkStation Help. Additional features are described in this manual, starting on page 19.

TO ACCESS COMMAND WORKSTATION HELP

1 Start Command WorkStation.

Select the Fiery EXP6000/EXP5000 from the Server List dialog box, and log on to the server.

For information about the default Administrator password for the Fiery EXP6000/EXP5000, see *Configuration and Setup*.

Job Status	Job Title	User	Date/Time	Copi.	Size
Held	test2000.pdf	Administrator	1/14/05 7:59:56 PM		28786 KB
Held	2Pletter.PDF.dbp	Administrator	1/9/05 11:28:31 AM	1	40296 KB
Held	2Pletter.PDF	Administrator	1/9/05 11:28:31 AM	1	28786 KB
Held	BMW.pdf	Administrator	1/9/05 11:09:39 AM	1	40296 KB
Held	simplex.pdf	Administrator	1/9/05 10:18:39 AM	1	19996 KB
Held	Black_Hole.pdf.dbp	Administrator	1/9/05 10:16:15 AM	1	33487 KB
Waiting	Black_Hole.pdf	Administrator	1/9/05 10:16:15 AM	3	33487 KB
Processing	simplex.pdf	Administrator	1/10/05 5:50:30 AM	1	19996 KB
Held	BigNum32.pdf.dbp	Administrator	1/9/05 4:54:14 PM	1	1596 KB
Held	S08368 Shoprite 5...	Administrator	1/9/05 2:24:31 PM	1	33447 KB
Held	S08378 Shoprite FS...	Administrator	1/9/05 2:24:30 PM	1	4686 KB
Held	S08381 Shoprite C...	Administrator	1/9/05 2:24:28 PM	1	3771 KB
Held	portrait_200.eps	Administrator	1/15/05 3:43:09 PM	1	19954 KB
Held	Man.ROB.eps	Administrator	1/15/05 3:42:09 PM	1	33447 KB
Waiting	12rings.pdf	Administrator	1/15/05 12:14:53 PM		18119 KB
Printing	testPage	Administrator	1/15/05 10:38:45 AM		816 KB

Printed Jobs	Job Title	User	Date/Time	Copi.
	B2BRGBCR.PS	Administrator	1/17/05 11:14:53 AM	15
	B34CMYKD.PS	Administrator	1/17/05 11:14:52 AM	15
	Associates-0394.pdf	Administrator	1/17/05 13:38:09 AM	1
	Printer Test Page	Administrator	1/16/05 5:29:20 PM	1
	Printer Test Page	Administrator	1/16/05 5:29:14 PM	1
	Printer Test Page	Administrator	1/16/05 5:29:01 PM	1
	Test Page	Administrator	1/16/05 3:29:38 PM	1
	Test Page	Administrator	1/16/05 3:16:13 PM	1
	EPGuide.pdf	Administrator	1/16/05 12:02:31 PM	3

2 Choose Help from the Help menu.

Additional features

The following sections describe how to use the additional features of Command WorkStation that are not discussed in Command WorkStation Help.

Align Trays

The Align Trays feature allows you to adjust the placement of text and images on a page so they are correctly aligned on a sheet of paper. This ensures that both sides of a duplex sheet have exactly the same alignment.

You can also perform tray alignment from the Fiery EXP6000/EXP5000 Control Panel by choosing Tray Alignment from the Functions menu.



To perform tray alignment, you must log on to the Fiery EXP6000/EXP5000 with Administrator privileges.

TO ALIGN TEXT AND IMAGES FOR PRINTING

- 1 In the Active Jobs window, select the connected Fiery EXP6000/EXP5000 for which you want to perform tray alignment.

If the Active Jobs window is hidden, choose Active Jobs from the Window menu to display it.

- 2 Choose Align Trays from the Server menu.

A dialog box containing the Tray Alignment options appears.

Paper Tray Alignment - AERO

1. Select trays

Tray: <tray selection> Media: Letter

Last Alignment 1/1/03

2. Print Alignment Page

Print duplex

3. Enter alignment values

Side 1			Side 2		
A	B	C	A	B	C
25	25	25	25	25	25

4. Apply alignment values

- 3 Choose the tray you want to align from the Tray menu.
- 4 Choose the paper size loaded in the tray from the Media menu.

NOTE: The alignment is specific to the combination of tray and paper size specified. If you align a given tray with Letter paper, and then load Legal paper into that tray, the alignment is wrong. You must perform a new alignment for each combination of tray and paper size.

- 5 **In the Print Alignment Page area, select the Print duplex option to print a duplex page, or clear the option to print a simplex page.**
- 6 **Click Print.**
- 7 **After the Alignment Page is printed, follow the instructions on the page.**

Fold the page exactly in half horizontally, unfold it, and then fold it in half vertically. When you unfold the sheet, observe that the fold lines cross three scales on three sides of the page. Determine which number on the scale each fold line crosses.
- 8 **In the Enter alignment values area, type the value that appears where the fold crosses each of the three scales, marked A, B, and C, for Side 1. If you choose to align for duplex printing, type the values for the three scales on Side 2 of the page, as well.**

NOTE: If you type different values in A and C, the image rotates, leading to uneven areas on printed output. If this occurs, type the same value in A and C.
- 9 **After you type the alignment values, click Apply, and then click Check Alignment to print the new alignment page.**
- 10 **To remove the alignments, select a tray and click Defaults in the Enter alignment values area.**
- 11 **Click Done.**

Printing Groups

The Printing Groups feature allows you to restrict print access to the Fiery EXP6000/EXP5000. When you define a printing group and password, users must type the group name and password in order to print jobs to the Fiery EXP6000/EXP5000.

For Printing Groups settings to take effect, the Fiery EXP6000/EXP5000 administrator must set the Enable Printing Groups option to Yes in Setup. For more information, see *Configuration and Setup*.



To define printing groups, you must log on to the Fiery EXP6000/EXP5000 with Administrator privileges.

TO DEFINE A PRINTING GROUP

- 1 **Choose Server > Printing Groups.**
- 2 **Click Create.**
- 3 **Type a Group name and password.**
- 4 **Click Add.**

To modify the name or password of a printing group, click Modify. To delete a printing group, click Remove.

Reorder Jobs

The Fiery EXP6000/EXP5000 processes and prints batches of selected jobs in order of each job's place in the queue. The Reorder Jobs feature allows you to control the processing or printing priority by reordering the job queue. When you promote jobs in the queue, these jobs take priority over the rest of the jobs on the Fiery EXP6000/EXP5000.

For example, you can reorder the queue to group jobs with similar print options, such as media or tray selections. When you select the jobs and apply the Print command, batches of jobs with similar options are printed together.




To reorder jobs, you must log on to the Fiery EXP6000/EXP5000 with Administrator privileges.

TO REORDER JOBS

1 Choose Reorder Jobs from the Server menu.

The Reorder Jobs dialog box appears.



2 Click the tab for the type of job that you want to reorder.

The Fiery EXP6000/EXP5000 supports the reordering of spooled/held jobs, processed/held jobs, and jobs that are waiting to process.

3 Select the job(s) that you want to reorder.

Hold down Ctrl and click to select multiple jobs. Hold down Shift and click to select a range of jobs.

4 Reorder the selected job(s).

To shift the job priority up or down, click the Move Up or Move Down button. To move the job(s) to top or bottom priority, click the Move to Top or Move to Bottom button.

Jobs at the top of the list take priority over jobs at the bottom.

5 When you finish defining the order, click Done.

Schedule Printing

The Schedule Printing feature allows you to set a specific date and time for printing a job. Assign Schedule Printing settings to a job from the following areas:



- Printer driver (see *Print Options*)
- Job Properties window in Command WorkStation, Windows Edition (see Command WorkStation Help)
- Active Jobs window in Command WorkStation, Windows Edition (see the following procedure)

Command WorkStation also allows you to search for jobs that have been scheduled for printing.

TO SCHEDULE A JOB FOR PRINTING FROM THE ACTIVE JOBS WINDOW

- 1 Select a job in the Active Jobs window and choose Properties from the Actions menu.
- 2 Click the Destination tab.
- 3 In the dialog box that appears, click Schedule Printing, specify the date and time when you want the job printed, and then click OK.



NOTE: Display the scheduled date and time by adding a Schedule Printing information column to the Active Jobs window. For information about adding information columns, see Command WorkStation Help.

TO FIND SCHEDULED JOBS

- Choose Find Scheduled Jobs from the Edit menu.

A window displays the search results.

Rush Printing

The Rush Printing feature allows you to print a job immediately, pausing any other jobs that are currently printing. After the Rush Printing job is complete, the paused jobs resume printing.

TO MARK A JOB FOR RUSH PRINTING

- Select a job in the Active Jobs window and choose Rush Printing from the Actions menu, or right-click the job and choose Rush Printing from the menu that appears.

Mixed Media

The Mixed Media feature allows you to define the chapter divisions of a job, print ranges of pages on varying types of media, insert blank media between pages, and insert tab media containing text labels.




The following guidelines and restrictions apply to Mixed Media settings:

- The Mixed Media dialog box restricts you from specifying settings that conflict with any media, page size, or finishing settings that have been specified for the job in the Job Properties dialog box or printer driver.
- When two or more Mixed Media settings are in conflict with each other, the Mixed Media dialog box highlights the setting names in red, signaling you to resolve the conflict.
- When you specify print options (in the Job Properties dialog box or printer driver) after specifying Mixed Media settings, certain print options may conflict with the page-specific Mixed Media settings. You must resolve the conflict by choosing different print options or removing certain Mixed Media specifications.
- Mixed Media settings affect the use of output color profiles when the “Use media defined profile” option is selected in ColorWise Pro Tools. For more information, see *Color Printing*.
- If counters are configured for the digital press, blank media inserted between pages do not count as printed pages.

TO DEFINE MIXED MEDIA SPECIFICATIONS

- 1 Select a spooled/held job in the Active Jobs window and choose Mixed Media Setup from the Actions menu.

The Mixed Media dialog box lists any previously defined media settings and includes buttons for defining, modifying, and removing settings.



NOTE: The Job Properties dialog box opens behind the Mixed Media dialog box. Do not close the Job Properties dialog box until you finish defining Mixed Media settings.

- 2 For Chapter Start Page(s), type the page numbers on which you want to start new chapter sections.**

Type page numbers as comma-separated values (for example: 4,9,17) to designate the start of each new chapter. This feature forces each starting page to use a right-side page, adding a preceding left-sided blank, if required.

NOTE: It is not necessary to type the first page, and page numbers refer to the numbering of the original document.

- 3 To apply finishing options (for example, stapling or sorting) to each chapter created with the Chapter Start feature, select the “Define Each Chapter As A Separate Finishing Set” option.**

NOTE: Not all finishing options can be applied to chapters that contain mixed media sizes (for example, Letter and A4).

- 4 To define properties for front and back covers, click Define Cover.**

For more information, see [“To define cover media settings”](#) on page 25.

- 5 To define properties for individual pages or page ranges, click Define Page Range.**

For more information, see [“To define media for specific pages”](#) on page 26.

- 6 To insert tab media, click Insert Tab.**

The Insert Tab dialog box appears. For information about defining tab settings, see [page 27](#).

NOTE: The Insert Tab feature is not available for imposed jobs.

- 7 To insert blank pages, click Insert Blank.**

For more information, see [“To insert blank pages”](#) on page 26.

- 8 To modify or delete a current definition, select it in the Mixed Media Definition list, and click Edit or Remove.**

If you click Edit, type new settings for the definition and click Modify.


- 9 After you finish defining Mixed Media settings, click OK to close the Mixed Media dialog box, and then click OK again to close the Job Properties dialog box.**

The Mixed Media settings are applied to the job.

TO DEFINE COVER MEDIA SETTINGS

- 1 In the Mixed Media dialog box, click Define Cover.

The Cover Media dialog box appears.



- 2 To define identical front cover and back cover media, select the “Apply the same settings for both front and back cover” option. To define media settings for the front or back cover individually, select the Front Cover or the Back Cover option.
- 3 Define duplexing, media, and paper source settings as required.
- 4 For Cover Page Mode, define how you want the content printed on the cover. You can specify printing on the front side only, back side only, or both sides of the cover page.

The following restrictions apply to Cover Page Mode settings:

- If you specify Print on Front Only, you must set the Duplex setting to Off.
- If you specify Print on Back Only or Print on Both Sides, you must set the Duplex setting to Head to Head or Head to Toe. The Duplex setting determines the orientation of the cover content.

- 5 Click OK to return to the Mixed Media dialog box.




Cover Media settings take precedence over settings defined in the Page/Page Range Media dialog box.

TO DEFINE MEDIA FOR SPECIFIC PAGES

- 1 Click **Define Page Range** in the **Mixed Media** dialog box.

The **Page/Page Range Media** dialog box appears.



- 2 Type pages and page ranges as comma-separated values (for example: 3,9–14,18).
- 3 Define duplexing, media, and paper source settings as required.

If you assign a new media type to the back side of a duplexed sheet, a blank page is inserted to force the assigned page content to the front side of the next sheet.


NOTE: Transparencies are supported only when Duplex is set to Off for all pages.

- 4 Click **Add Definition** after each media setting you define.
- 5 Click **Close** to return to the **Mixed Media** dialog box.

TO INSERT BLANK PAGES

- 1 Click **Insert Blank** in the **Mixed Media** dialog box.

The **Insert Blank** dialog box appears.



- 2 Indicate whether to insert the blank before or after the target page. Define the target page as the first or last page in the document or a specific numbered page.
- 3 Define media, paper source, and page size settings for the blank page.
- 4 Click **Insert** after each blank page you define.
- 5 Click **Close** to return to the **Mixed Media** dialog box.

Insert Tab

The Insert Tab feature allows you to automatically insert tab pages throughout a job. This feature accommodates various sizes and types of tab media stock. Users can insert the tab text and override text attributes on a per-job basis.

NOTE: The Insert Tab feature is not available for imposed jobs.

NOTE: When you configure counters for the digital press, printed tab pages count as black-and-white pages, provided colors are calibrated to use pure black toner. Expelled tabs are not counted as printed pages.


TO INSERT TAB PAGES

- 1 **Select a spooled/held job in the Active Jobs window, and choose Mixed Media Setup from the Actions menu.**

The Mixed Media dialog box appears.

- 2 **Click Insert Tab in the Mixed Media dialog box.**

The Insert Tab dialog box appears.



- 3 **To load a previously saved tab setting, click Load Setting, highlight the desired tab setting, and then click Select.**
- 4 **Type the number of tab pages that you want to insert into the document in the “Total number of tabs” field.**
- 5 **Type the number of tab positions included in a complete tab set in the “Number of tabs in a set” field.**

This specification ensures that tab text is printed in the correct tab positions. For example, tab positions in a set consisting of 10 tabs are distinct from tab positions in a set consisting of five tabs.

- 6 **Specify media type, paper source, and page size settings for the tab stock.**

Page Size values refer to the dimensions of the stock, including the tabbed portion.


7 To specify attributes for the tab text, click Text Attributes.

You can also set text attributes after you close the Insert Tab dialog box. For more information, see “To specify tab text” on page 28.

8 To save the current Insert Tab specifications as a tab setting, click Save Setting. Assign the tab setting a name, and then click Save.

9 After you finish specifying the tabs, click OK to close the Insert Tab dialog box.

The Tabs Text dialog box appears. Use the following procedure to define the tab text.




TO SPECIFY TAB TEXT

1 In the Tabs Text dialog box, select the “Apply same text attributes for all tabs” option if you want all tabs to use the same text attributes. Click Text Attributes.

Specify the rotation, alignment, font, and size attributes of the tab text, and then click OK.

2 Indicate where you want each tab inserted in the document.

- In the Page field, type the page number where you want the tab inserted.
- Use the insertion icon to control whether the tab is inserted before or after the specified page number. Click the icon to toggle between insertion modes. The icon preview and ToolTip change to reflect the current insertion mode. To display the ToolTip, position the pointer over the insertion icon.



NOTE: If you define a tab to be inserted between an odd-numbered page and an even-numbered page in a duplex job, the tab is inserted after the odd-numbered page on the first sheet, and the even-numbered page is printed on the next sheet.

3 Type the desired tab text for each tab in the Tab Text field.

To define text attributes for each tab individually, click Text Attributes for that tab.

4 To modify media settings for the tabs, click Change Tab Settings.

For more information, see “[To insert tab pages](#)” on page 27.

5 After you finish specifying tab text, click OK to close the Tabs Text dialog box.

The Mixed Media dialog box displays the current tab settings in the Mixed Media Definition list.

6 To apply your Insert Tab settings to the document, click OK to close the Mixed Media dialog box, and then click OK again to close the Job Properties dialog box.

Soft Proofing



Soft Proofing allows you to view accurate color previews of print jobs on a monitor. This feature is available only if Fiery Graphic Arts Package is installed and enabled on the Fiery EXP6000/EXP5000.

For information about using Soft Proofing, see the *Fiery Graphic Arts Package*.

EFI ImageViewer



If the Fiery Graphic Arts Package, Premium Edition is installed and enabled on the Fiery EXP6000/EXP5000, you can use EFI ImageViewer to preview and edit jobs. For information about using ImageViewer, *Fiery Graphic Arts Package*.



NOTE: When available, ImageViewer replaces the standard full-screen preview window described in Command WorkStation Help.

Troubleshooting



To troubleshoot basic connection and software problems with Command WorkStation, see the following sections. For additional troubleshooting information, see Command WorkStation Help.

Command WorkStation cannot connect to the Fiery EXP6000/EXP5000

If you cannot connect to the Fiery EXP6000/EXP5000 or locate the Fiery EXP6000/EXP5000 from your computer, contact your network administrator. The administrator may need to troubleshoot your network connections and check settings on the servers that you use for printing. If settings have changed, you may need to reconfigure the Fiery EXP6000/EXP5000 (see *Configuration and Setup*).

For example, if objects in your Novell network environment are removed or renamed, or accounts or permissions are changed, the Print Server administrator may need to edit settings or configure new settings in IPX (Novell) Setup to reflect the new configuration.

If you can connect to the Fiery EXP6000/EXP5000 with another utility, you may need to reconfigure the Command WorkStation connection to the Fiery EXP6000/EXP5000 (see [page 15](#)).

If you configured the Fiery EXP6000/EXP5000 and set up client computers and network servers according to the instructions in *Configuration and Setup*, print a Test Page. If you can print the Test Page but still cannot print a document from a remote computer, contact the network administrator to troubleshoot your network connection.

If you cannot connect and cannot print a Test Page, check the Control Panel of the digital press.

Command WorkStation does not respond

If Command WorkStation is unresponsive, use the following troubleshooting guidelines.

IF COMMAND WORKSTATION WINDOWS DO NOT UPDATE

- 1 **Log off and then quit Command WorkStation.**
- 2 **Restart Command WorkStation or restart the computer.**

If the Command WorkStation windows do not update or no jobs are displayed, and the mouse has no effect (you cannot select a job or a window, use a right mouse command, or select a menu item), the Print Server is offline or network communication has failed.

TO FORCE AN EXIT FROM COMMAND WORKSTATION

- 1 **Press Ctrl-Alt-Delete and use the Program Manager to close Command WorkStation.**
- 2 **At the Fiery EXP6000/EXP5000, disconnect and reconnect the network cable, and then try printing a Test Page or Configuration page.**
- 3 **If that fails, restart the Fiery EXP6000/EXP5000.**

EFI IMPOSE

EFI Impose is a utility that you access from Command WorkStation, Windows Edition. Impose allows you to do the following:

- Apply imposition layouts to jobs for custom printing, binding, and cutting.
- Apply impositions to variable data jobs.

Installing and enabling Impose

The following sections describe how to install and enable Impose.

Installing Impose

The Impose software is automatically installed when you install Command WorkStation, Windows Edition from the User Software CD.



Do not attempt to install Impose from the User Software CD (by starting the setup.exe from the Impose folder). Impose is automatically installed when you install Command WorkStation. Installing Impose separately from the User Software CD can cause unpredictable results.

To enable Impose on a client workstation, you must:

- Install Adobe Acrobat and the Enfocus PitStop plug-in module.
- Install the Impose software protection key (dongle) into the parallel port or USB port of the client workstation.



If you see a dongle installed on the workstation, Impose has already been enabled and is ready for use. If the dongle is not installed, see the documentation that accompanies the Impose kit.

Installing Adobe Acrobat and Enfocus PitStop

To use Impose, you must install Acrobat, PitStop (a plug-in for Acrobat for use with Impose), and Command WorkStation, Windows Edition. Install Acrobat before you install PitStop.

NOTE: If you install Acrobat after Command WorkStation, you may need to restart Command WorkStation in order to use Impose.

For more information about Acrobat, see the ReadMe file inside the Acrobat 6.0 folder on the Adobe Acrobat CD.



TO INSTALL ADOBE ACROBAT

NOTE: Adobe Acrobat v6.0 is provided for Impose. We recommend that you remove any other versions of Acrobat installed on your computer.

- 1 Uninstall all versions of Acrobat currently installed on your computer.**
- 2 Insert the Adobe Acrobat CD with the language that you want into the CD-ROM or DVD drive.**

If a Windows screen appears asking “What do you want Windows to do?” click Cancel or select the “Open the folder to view files using Windows Explorer” option.

- 3 Navigate to the location of the CD-ROM or DVD drive, and double-click the Install.exe icon.**

NOTE: Use only Install.exe. Do not navigate to any of the subfolders inside the Acrobat 6.0 folder. Using setup.exe from these subfolders can result in an incomplete installation and cause system problems.

- 4 Follow the on-screen instructions.**

At the Select EULA Language screen, select the language in which you want to view the end user license agreement.

- 5 After installation is complete, remove the CD.**

TO INSTALL PITSTOP

- 1 Insert the Enfocus PitStop CD into the CD-ROM or DVD drive.**
- 2 Navigate to the location of the CD-ROM or DVD drive, and double-click the Setup.exe icon.**

NOTE: Use only Setup.exe on the root level of the CD. Do not navigate to the Runtime folder on the CD. Using setup.exe from the Runtime folder can result in an incomplete installation and cause system problems.

- 3 Follow the on-screen instructions to complete PitStop installation.**

When prompted, accept the default location for PitStop installation.

For more information, see the documentation that accompanies PitStop. To access the documentation, start Acrobat and choose Help > Plug-in Help > Enfocus PitStop Professional.

Using Impose



Complete instructions about how to use Impose are provided in Command WorkStation, Windows Edition Help.

TO ACCESS IMPOSE HELP

- 1 Start Command WorkStation, Windows Edition.
- 2 Choose Help from the Help menu.
- 3 Use the Contents, Index, or Search panes to navigate to the Impose Help topics.

COMMAND WORKSTATION, MACINTOSH EDITION

Command WorkStation LE (also known as Command WorkStation, Macintosh Edition) allows operators of the Fiery EXP6000/EXP5000, or users with Operator or Administrator privileges, to monitor and manage the print workflow of jobs on the Fiery EXP6000/EXP5000.

Command WorkStation LE enables you to do the following:

- View the print status of jobs on the Fiery EXP6000/EXP5000.
- Hold, process, and print jobs.
- Override user-assigned print option settings.
- Preview the page content of a job.
- Reorder pages in a job and combine pages from different jobs.
- Create and use FreeForm master files for variable data printing.
- Archive job files.
- View job logs of recent print activity.

Installing Command WorkStation, Macintosh Edition

Install Command WorkStation, Macintosh Edition on a Mac OS X computer that has a network connection to the Fiery EXP6000/EXP5000. For complete system requirements, see *Welcome*.



Before installing the utility, make sure you have completed the preliminary procedures described in “Preparing for installation on Mac OS 9 computers” on page 11.

TO INSTALL COMMAND WORKSTATION, MACINTOSH EDITION

- 1 Insert the User Software CD into the CD-ROM drive of the Mac OS X computer.
- 2 Navigate to the location of the User Software CD, and open the OSX folder.
- 3 Double-click the Command WorkStation LE icon.
- 4 Follow the on-screen instructions to complete the installation.

Configuring the connection to the Fiery EXP6000/EXP5000

The first time you start Command WorkStation, you are prompted to configure the connection to the Fiery EXP6000/EXP5000.

You can also edit the configuration whenever there is any change to your Fiery EXP6000/EXP5000 server or network, such as a changed server name or IP address. If you change Fiery EXP6000/EXP5000 Setup information, do so before you reconfigure the connection.

BEFORE YOU BEGIN

- **Print the Fiery EXP6000/EXP5000 Configuration page.**


For instructions about printing the Configuration page, see *Configuration and Setup*.

This page contains information you need when configuring the connection, such as the IP address of the Fiery EXP6000/EXP5000. For TCP/IP installations, you can use the DNS name instead of the IP address. Make sure the Fiery EXP6000/EXP5000 is already registered in a Domain Name Server (DNS) on your network. For more information, see the documentation that accompanies your network system.

TO CONFIGURE THE CONNECTION FOR COMMAND WORKSTATION, MACINTOSH EDITION

- 1 **Open the Applications: Command WorkStation folder on the Mac OS X hard disk. Double-click the CWS file to start the application.**

The Available Servers dialog box appears. All servers found in the local subnet are displayed.



- 2 **If no Fiery EXP6000/EXP5000 servers were found, click the Manual tab to search by DNS name or IP address. Click Add to add the server to the Available Servers list.**



- 3 **Click the Auto Search tab and then click Advanced to search by a range of IP addresses or the IP address and subnet mask.**

All available servers are displayed in the Available Servers list.

4 Select the Fiery EXP6000/EXP5000 server that you want to use and click Add.

The selected Fiery EXP6000/EXP5000 server is displayed in the Login Server list.



5 Click the server name.

The Login dialog box appears.



6 Select the Administrator, Operator, or Guest key, and then click Login.

Your computer is connected to the server.

For information about the default Administrator password for the Fiery EXP6000/EXP5000, see *Configuration and Setup*.

To modify the Command WorkStation connection to the Fiery EXP6000/EXP5000, you must remove the server from the Login Server list and follow the procedure for configuring the connection.

Using Command WorkStation, Macintosh Edition

Once you have installed and configured Command WorkStation, you can begin using it to monitor and manage jobs on the Fiery EXP6000/EXP5000.




Complete instructions about how to use the Command WorkStation features are provided in Command WorkStation Help.

TO ACCESS COMMAND WORKSTATION HELP

1 Start Command WorkStation.

Select the Fiery EXP6000/EXP5000 in the server list, and log on to the server.

For information about the default Administrator password for the Fiery EXP6000/EXP5000, see *Configuration and Setup*.



2 Choose Help from the CWS menu.

Troubleshooting

When troubleshooting basic connection and software problems with Command WorkStation, see the following sections. For additional troubleshooting information, see Command WorkStation Help.

Command WorkStation cannot connect to the Fiery EXP6000/EXP5000

If you are unable to connect to the Fiery EXP6000/EXP5000, or are unable to locate the Fiery EXP6000/EXP5000 from your computer, your network administrator may need to troubleshoot your network connections and check the settings on the servers you print to. If settings have changed, it may be necessary to reconfigure the Fiery EXP6000/EXP5000.

For example, if objects in your Novell network environment are removed or renamed, or accounts or permissions are changed, the Print Server administrator may need to edit the settings or reconfigure new settings in IPX (Novell) Setup to reflect the new configuration.

If you are able to connect to the Fiery EXP6000/EXP5000 with another utility, you may need to reconfigure the Command WorkStation connection to the Fiery EXP6000/EXP5000 (see [page 38](#)).

If you configured the Fiery EXP6000/EXP5000 and set up client computers and network servers according to the instructions in *Configuration and Setup*, try printing a Test Page.

If you can print the Test Page but still cannot print a document from a remote computer, contact your network administrator to troubleshoot the network connection.

If you cannot connect and cannot print a Test Page, check the Control Panel of the digital press.

Command WorkStation does not respond

Use the following troubleshooting guidelines if Command WorkStation is unresponsive.

IF COMMAND WORKSTATION WINDOWS DO NOT UPDATE

- 1 **Log off and then quit Command WorkStation.**
- 2 **Restart Command WorkStation or restart the computer.**

If the Command WorkStation windows do not update, or no jobs are displayed, and the mouse has no effect (you cannot select a job or a window, use a Control-click command, or select a menu item), the Print Server is offline or network communication has failed.

TO FORCE AN EXIT FROM COMMAND WORKSTATION

- 1 **Press Command-Option-Escape and use the Force Quit Applications dialog box to close Command WorkStation.**
- 2 **At the Fiery EXP6000/EXP5000, disconnect and reconnect the network cable, and then try printing a Test Page or Configuration page.**
- 3 **If printing fails, restart the Fiery EXP6000/EXP5000.**

FIERY DOWNLOADER

Downloader allows you to transfer job files and fonts from your computer to the Fiery EXP6000/EXP5000. With Downloader, you can do the following:

- Check the print status of the Fiery EXP6000/EXP5000.
- Manage fonts on the Fiery EXP6000/EXP5000 hard disk.
- Send the following types of files directly to the Fiery EXP6000/EXP5000 for printing, without opening the application in which they were created:
 - PostScript (PS)
 - Encapsulated PostScript (EPS)
 - Creo Variable Print Specification (VPS)
 - Tagged Image File Format (TIFF)
 - Portable Document Format (PDF)

Installing Downloader

To install and use Downloader, you must have a Windows or Mac OS computer with a network connection. For detailed system requirements, see [Welcome](#).

The installers for Downloader are located on the User Software CD.



Before installing the utility, make sure you have completed the preliminary procedures described on [page 10](#) and [page 11](#).

TO INSTALL DOWNLOADER ON A WINDOWS COMPUTER

- 1 Insert the User Software CD into the CD-ROM drive of the computer.
- 2 Navigate to the location of the User Software CD, and open the Fiery Downloader folder.
- 3 Double-click the setup.exe icon.
- 4 Follow the on-screen instructions to complete the installation.

TO INSTALL DOWNLOADER ON A MAC OS COMPUTER

- 1 Insert the User Software CD into the CD-ROM drive of the computer.
- 2 Navigate to the location of the User Software CD and open the OS9 folder.
- 3 Double-click the Fiery Downloader icon.
- 4 Follow the on-screen instructions to complete the installation.

Configuring the connection to the Fiery EXP6000/EXP5000

The first time you start Downloader, you must configure the connection to the Fiery EXP6000/EXP5000.

BEFORE YOU BEGIN

- **Print the Fiery EXP6000/EXP5000 Configuration page.**

For more instructions about printing the Configuration page, see *Configuration and Setup*.

This page contains information you need when configuring the connection, such as the IP address of the Fiery EXP6000/EXP5000. For TCP/IP installations, you can use the DNS name instead of the IP address. Make sure the Fiery EXP6000/EXP5000 is already registered in a Domain Name Server (DNS) on your network. For more information, see the documentation that accompanies your network system.

TO CONFIGURE THE CONNECTION FOR FIERY DOWNLOADER

- 1 **Start Downloader.**
- 2 **If the No Servers Configured dialog box appears, click OK. If the Choose Printer Device dialog box appears, click Add.**
- 3 **Type the appropriate information for the Fiery EXP6000/EXP5000.**

Nickname—Type a name for the Fiery EXP6000/EXP5000. This name does not have to match the actual Server Name of the Fiery EXP6000/EXP5000.

NOTE: The nickname cannot contain the following characters:
[] _ " ' <space> <tab>


Protocol—Choose the type of network protocol you are using from the menu.

NOTE: Downloader is not supported over IPX/SPX.

Server Name—Type the IP address (or DNS name) of the Fiery EXP6000/EXP5000.

New Device—Type the name of the device the Fiery EXP6000/EXP5000 is connected to: DC6060 or DC5252.


NOTE: Type DC6060 or DC5252 exactly as shown; the device name is case-sensitive.



- 4 When you have typed all the information, click **Add**.
- 5 With the device name (**DC6060** or **DC5252**) selected in the **Devices** list, click **OK**.

The Fiery EXP6000/EXP5000 appears in the list of Available Servers. The first line of the entry displays the nickname you assigned the server, followed by the protocol you chose. The second line displays the device name.

Device name of the
Fiery EXP6000/EXP5000
(DC6060 or DC5252)



- 6 With the device name selected in the list of Available Servers, click **Select** to begin using the utility.

Modify the configuration whenever there is any change to your Fiery EXP6000/EXP5000 server or network, such as a server name or IP address. If you change Fiery EXP6000/EXP5000 Setup information, do so before reconfiguring the connection.

To MODIFY THE CONFIGURATION

- 1 To edit information for a Fiery EXP6000/EXP5000 in the list of available servers, select the Fiery EXP6000/EXP5000 by its nickname and click **Modify**.
- 2 Make the necessary changes in the **Modify Server Settings** dialog box and click **OK**.
- 3 To add a new Fiery EXP6000/EXP5000 to the list of available servers, click **Add**. Configure the **Add New Server** dialog box as outlined in steps 3 through 5 in the previous procedure.
- 4 To remove a Fiery EXP6000/EXP5000, select the Fiery EXP6000/EXP5000 by its nickname and click **Remove**.

NOTE: The nickname cannot be modified.

Using Downloader

NOTE: The Windows and Mac OS version of Downloader are fundamentally the same; differences are noted in this section. Where both windows or dialog boxes are illustrated, the Windows version appears first, followed by the Mac OS version.

Viewing print status

Use the following procedure to check the print status of the Fiery EXP6000/EXP5000.

TO VIEW PRINT STATUS WITH DOWNLOADER

- 1 Double-click the Fiery Downloader icon or choose Fiery Downloader from the Start > Programs > Fiery menu.
- 2 Select the Fiery EXP6000/EXP5000 in the Chooser window and click OK (Windows) or Connect (Mac OS).

The Fiery Downloader status window appears, displaying the Downloader toolbar, menus, and status bar.


Windows

- 1 Displays server status and user and document name of the job currently printing
- 2 Displays server status and user and document name of the job currently processing
- 3 Dynamically displays the progress of the job
- 4 Displays the amount of available disk space



Mac OS

- 1 Displays server status and user and document name of the job currently printing
- 2 Displays server status and user and document name of the job currently processing
- 3 Dynamically displays the progress of the job
- 4 Displays the amount of available disk space



Buttons for some menu functions appear in the toolbar at the top of the window.

	Open	Click to connect to a different Fiery EXP6000/EXP5000.
	Download	Click to download a file or font to the Fiery EXP6000/EXP5000.
	Status	If you are viewing the Font List, click to display the status window for the current Fiery EXP6000/EXP5000.
	Font List	If you are viewing the status window, click to display a list of printer fonts on the Fiery EXP6000/EXP5000 hard disk.
	About Fiery Downloader	Click to view version information about Downloader.

- 3 To view font information in the window, click the Font List button or choose Font List from the File menu.
- 4 To select a different Fiery EXP6000/EXP5000, choose Open from the File menu or click the Open button.
- 5 Select the Fiery EXP6000/EXP5000 in the dialog box that appears and click OK (Windows) or Connect (Mac OS).
- 6 To close the status window, choose Close from the File menu. To quit Downloader, choose Exit (Windows) or Quit (Mac OS) from the File menu.

Downloading files and printer fonts

You can download a variety of file types, as well as fonts, to the Fiery EXP6000/EXP5000. You can specify a limited number of print option settings for the files you download.

TO DOWNLOAD A FILE OR FONT WITH DOWNLOADER

1 Generate a file.


You can save a PostScript or PDF file by selecting the appropriate option in the application’s Print dialog box. With some applications, you can also save EPS and TIFF files.

If you experience problems printing EPS files with Downloader, print the file directly from the application in which you created it.


2 Start Downloader.

3 Choose Download from the File menu or click the Download button.

Windows



Mac OS



4 Choose the file type to display from the Files of type (Windows) or Show (Mac OS) menu.

All Known Formats lists all files in formats supported by Fiery Downloader.

NOTE: Choose All Files for TIFF files.

You can download files and fonts in the same batch. If the fonts are used by files in the same batch, the fonts download first.

5 Choose the Connection Type (Windows) or Queue (Mac OS) to which you download the files.

The options available to you in this menu depend on the setup at your site. The potential selections are Print queue (Windows) or Print (Mac OS), Hold queue (Windows) or Hold (Mac OS), and Direct Connection (Windows) or Direct (Mac OS). If your administrator has not enabled one or more of these connections, you cannot select it.

You cannot print PDF or TIFF files with the Direct connection. If you choose the Direct connection, the job is spooled to the Print queue and then printed. If the Print queue is not enabled, the job is spooled to the Hold queue and must be released for printing by the operator.

NOTE: To download fonts, you must use the Direct connection (make sure the Direct connection is published on the Fiery EXP6000/EXP5000). If you do not have access to the Direct connection, you must embed any special fonts used by the file when you generate it.

6 Select the file name and click Add File(s) (Windows) or Add (Mac OS).

The File name field (Windows) displays the name of the selected file before you click Add.

You can navigate to different drives and directories to select files to download. Click Add All (Mac OS) to add all files in a folder.

To select multiple sequential files (Windows), select the first file and then Shift-click the last file. Control-click to select multiple non-sequential files.



If you change your mind about a file, select the file name in the Files to Download list and click Remove File(s) (Windows) or Remove (Mac OS).

Click Remove All (Mac OS) to remove all files from the Files to Download list.

7 To change the attributes of a file to be downloaded, select it and click Options.


Mac OS

- 1 PostScript Options dialog box
- 2 PDF Options dialog box



Windows

- 1 PostScript Options dialog box
- 2 PDF Options dialog box



8 Specify the following information in the dialog box and click OK.

The options you set apply only to the selected file. You can set different options, or leave the default settings, for each file.

Copies: Type the number of copies.

Brightness (PostScript and EPS files only): Change the Brightness setting if a file appears to be too dark or too light. Choose 85% for a substantially lighter image, 115% for a substantially darker image, or one of the options in between.

NOTE: Some applications, including Adobe Photoshop, provide transfer functions that allow you to specify density settings for an image. If the file you are printing includes transfer functions, the Fiery Downloader Brightness option has no effect. For more information about using transfer functions, see the documentation that accompanies your application.

'showpage' after EPS files (Windows) or **'showpage'** (Mac OS) (PostScript and EPS files only): In most cases, you do not need to use this option. Select the 'showpage' option only if an EPS file fails to print without it. This option adds a 'showpage' PostScript language command at the end of the print job. Some applications omit this necessary PostScript language command when they generate EPS files. Select this option when printing EPS files generated by these applications. If you select this option unnecessarily, extra blank pages might print.


If you experience problems printing EPS files with Downloader, you can print the file directly from the application in which you created it.

Page range (PDF files only): Specify the page range you want to print.

- 9 Click **Download File(s)** (Windows) or **Download** (Mac OS).
- 10 To cancel downloading, press **Escape** (Windows) or **Command-.** (Mac OS).

TO CREATE A FONT BACKUP

- 1 Start Fiery Downloader.
- 2 Choose Back up fonts from the File menu.
- 3 Browse to the location in which to save the fonts.

Windows**Mac OS**

- 4 Create a new directory by clicking Create (Windows) or New Folder (Mac).
- 5 Click OK.

The font backup file is saved.

TO RESTORE FONTS

- 1 Start Fiery Downloader.
- 2 Choose Restore fonts from the File menu.
- 3 Open the font backup file from the saved location, and click OK (Windows) or Select this folder (Mac OS).

This replaces all the user fonts on the Fiery EXP6000/EXP5000.

Managing printer fonts

The Fiery EXP6000/EXP5000 includes 136 PostScript fonts. In addition, two Adobe Multiple Master fonts are included and used for font substitution in PDF files.

For a complete list of fonts, display the Font List (see [page 57](#)).

Before downloading a file that uses fonts not resident on the Fiery EXP6000/EXP5000, you must download the fonts (unless the fonts are embedded in the file). To see what fonts are resident on the Fiery EXP6000/EXP5000, choose Font List from the File menu or click the Font List button (see [page 50](#)).



You can download fonts only via the Direct connection. If you do not have access to the Direct connection, you must embed any special fonts used by the file when you generate it.

The screen fonts that correspond to the printer fonts installed on the Fiery EXP6000/EXP5000 are not automatically installed on your Windows system.



Downloader cannot download TrueType fonts. If you use TrueType fonts in Windows, convert them to Adobe Type 1 before printing. To convert to Adobe Type 1 fonts for Windows 98/Me, click the Fonts tab in the Adobe PS printer driver and set up the Font Substitution Table. For Windows NT 4.0, click the Postscript tab of the Fiery EXP6000/EXP5000 Document Defaults dialog box and select TrueType Font Setting > Download as Softfont. For Windows 2000/XP/Server 2003, click the Postscript tab of the Fiery EXP6000/EXP5000 Printing Preferences dialog box and select TrueType Font Setting > Download as Softfont.



You can change font settings in the printer driver to suit your printing needs. For more information, see the printer driver Help menu.

Printer fonts and Mac OS screen fonts

Like all PostScript fonts, the fonts included with the Fiery EXP6000/EXP5000 come in two forms: printer fonts and screen fonts. Install the screen fonts included with the Fiery EXP6000/EXP5000 user software on your Mac OS computer. If you are using these fonts in documents you print on a LaserWriter, they are probably already installed. If not, you must install them as described in “Fonts” on page 12.

Occasionally, you may want to use Adobe Type 1 (Windows) or PostScript (Mac OS) fonts that are not included with the Fiery EXP6000/EXP5000. If so, you must install both the screen fonts and the printer fonts on your computer. To do this, follow the instructions from the font manufacturer.

Downloading printer fonts to the Fiery EXP6000/EXP5000

In general, each time you print from within a Mac OS application, the application automatically downloads any fonts used in your document that are not already installed on the Fiery EXP6000/EXP5000, as long as the printer fonts are installed in your System Folder. These fonts remain in the Fiery EXP6000/EXP5000 only until your document has printed. If you reprint the same document, your application must download the fonts again.

If you regularly use one or more fonts from Windows or Mac OS applications that are not already installed in the Fiery EXP6000/EXP5000, you can save time by downloading them to the Fiery EXP6000/EXP5000 hard disk with Downloader. Fonts you download to the Fiery EXP6000/EXP5000 hard disk remain installed until you remove them using Downloader, no matter how many times the Fiery EXP6000/EXP5000 is turned off and on. Consider downloading fonts you use on a regular basis to the Fiery EXP6000/EXP5000 hard disk.



Before you download PostScript, TIFF, or EPS files with Downloader, make sure all fonts included in your file are installed on the Fiery EXP6000/EXP5000 or embedded in your file; otherwise, the text in these fonts does not print correctly or may not print at all. For PDF files, font substitution occurs automatically for fonts not installed on the Fiery EXP6000/EXP5000. Two multiple master fonts (a serif font and a sans serif font) stored on the Fiery EXP6000/EXP5000 are used exclusively for substitution with PDF files.

TO VIEW FONT INFORMATION, UPDATE, PRINT, AND DELETE FONTS


- **Choose Font List from the File menu or click the Font List button.**



If the Direct connection is not published, you cannot view the Font List or perform any of the tasks described in this procedure. For information about publishing the Direct connection, see *Configuration and Setup* or consult your administrator.

The Font List window includes Update, Print, and Delete buttons. The printer fonts included with the Fiery EXP6000/EXP5000 (resident fonts) are locked. Locked fonts appear with a Lock icon next to the name and cannot be deleted.

- 1 Click to update the information in the Font List window
- 2 Click to print the Font List to the Print queue
- 3 Select a font and click here to delete it
- 4 Lock icon



EFI HOT FOLDERS

Hot Folders is a utility that allows you to store and reuse frequently used print options when printing PostScript and PDF files on the Fiery EXP6000/EXP5000. With Hot Folders, you can do the following:

- Create special folders (hot folders) that assign specific print settings and print queues to jobs.
- Print jobs to the Fiery EXP6000/EXP5000 by dragging and dropping them onto hot folders on your computer's desktop.
- Monitor the status of jobs sent to hot folders.

Installing Hot Folders

To install and use Hot Folders, you need a Windows computer with a network connection. For detailed system requirements, see [Welcome](#).



To use Hot Folders from a Mac OS computer, ask the network administrator to share Hot Folders from a Windows NT, Windows 2000, or Windows XP server.

The installer for Hot Folders is located on the User Software CD.



Before installing the utility, make sure you complete the preliminary procedures described on [page 10](#).

TO INSTALL HOT FOLDERS

- 1 Insert the User Software CD into the CD-ROM drive of the computer.**
- 2 Navigate to the location of the User Software CD and open the EFI Hot Folders folder.**
- 3 Double-click the setup.exe icon.**
- 4 Follow the on-screen instructions to complete the installation.**

Using Hot Folders

Complete instructions about how to use the standard Hot Folders features are provided in Hot Folders Help.



If Fiery Graphic Arts Package, Premium Edition is installed and enabled on the Fiery EXP6000/EXP5000, you can use additional file format filters with Hot Folders. For information about using these file format filters, see *Fiery Graphic Arts Package*.

TO ACCESS HOT FOLDERS HELP



- 1 **Start Hot Folders.**
- 2 **Choose Help > EFI Hot Folders Help.**

FIERY WEBTOOLS

WebTools allows you to manage your Fiery EXP6000/EXP5000 remotely from the Internet or your company's intranet. The Fiery EXP6000/EXP5000 has its own home page, where you can select from the following WebTools:

- **Status** provides current information on the jobs processing and printing on the Fiery EXP6000/EXP5000.
- **WebLink** provides all remote users the same link to a predefined WebLink destination.
- **WebSetup** allows the Fiery EXP6000/EXP5000 Administrator to view and modify Setup options remotely.
- **WebDownloader** allows remote users to download PostScript, EPS, PDF, and ASCII files directly to the Fiery EXP6000/EXP5000.
- **Installer** allows remote users to download installers (for drivers, PPDs, and other printer files) directly from the Fiery EXP6000/EXP5000.
- **Software Updates** allows remote users to download system software updates for the Fiery EXP6000/EXP5000.

Setting up WebTools

WebTools is resident on the Fiery EXP6000/EXP5000 hard disk and does not require special installation. However, WebTools does require initial setup by the Fiery EXP6000/EXP5000 Administrator.

To enable network users to access and use WebTools, the Administrator must set specific options in Network Setup and Printer Setup. For information about these specific Setup options, see *Configuration and Setup*.

The Administrator also must prepare each user's computer to communicate with the Fiery EXP6000/EXP5000 over the Internet or intranet.

TO SET UP CLIENT COMPUTERS TO USE WEBTOOLS

- 1 **Enable TCP/IP networking.**
- 2 **Make sure the workstation has a valid, unique IP address.**
- 3 **Make sure a supported Internet browser is installed on the computer.**

For more information about supported browsers, see *Welcome*.

- 4 **Make sure Java is enabled in your Internet browser.**



In addition, make sure you complete the preliminary procedures described on [page 10](#).

Accessing the WebTools home page

Use your Internet browser to access WebTools. For complete information about browser and system requirements, see [Welcome](#).

TO ACCESS THE WEBTOOLS HOME PAGE

- 1 **Start your Internet browser.**
- 2 **Type the IP address or DNS name of the Fiery EXP6000/EXP5000.**

The Fiery EXP6000/EXP5000 home page appears.

If the home page for the digital press appears instead of the WebTools page, click the WebTools link.

- 3 **Click the link for the WebTool that you want to use.**

Using WebTools

The following sections describe how to use the WebTools.

Status

Status lets you view jobs that are currently processing and printing on the Fiery EXP6000/EXP5000. Printing and processing information is updated every 30 seconds.

The Status window automatically closes when you go to a different destination with your browser. Use the Float option to leave the Status window open to continue checking the status of the Fiery EXP6000/EXP5000. As long as you keep the Status window open, it is dynamically updated every 30 seconds.

TO USE STATUS

- **Click Status in the WebTools home page.**

Use the Status window to monitor the RIPping (processing) and printing status of the Fiery EXP6000/EXP5000.

TO OPEN A NEW BROWSER WINDOW FOR STATUS

- 1 **Click Status in the WebTools home page.**
- 2 **Click Float.**

WebLink

WebLink provides a link to another web page that contains additional information regarding the Fiery EXP6000/EXP5000 or digital press.

The Fiery EXP6000/EXP5000 Administrator can change the default WebLink destination.

TO CHANGE THE WEBLINK DESTINATION

NOTE: This procedure requires the Administrator password.

- 1 **Start Internet Explorer.**
- 2 **Type the IP address or the DNS name of the Print Server.**
- 3 **Type the Administrator password, if required, and click OK.**
- 4 **Press the Control key (Mac OS) or Ctrl key (Windows) as you click WebLink.**

The Update WebLink dialog box appears.

- 5 **Type the new WebLink address (URL) and click OK.**

WebSetup

WebSetup allows the Fiery EXP6000/EXP5000 Administrator to view and modify Setup options remotely from a Windows computer. For complete information about using WebSetup, see *Configuration and Setup*.



Before using WebSetup, make sure you complete the WebSetup preparation procedure described on [page 10](#).

WebDownloader

WebDownloader allows you to send PostScript (PS), Encapsulated PostScript (EPS), Tagged Image File Format (TIFF), and Portable Document Format (PDF) files directly to the Fiery EXP6000/EXP5000 without using the applications in which they were created.

TO DOWNLOAD FILES WITH WEBDOWNLOADER

- 1 Click **WebDownloader** on the **WebTools** home page.
- 2 Select the **print connection**.

Downloaded files can be sent to the Print or Hold queues, or to the Direct connection of the Fiery EXP6000/EXP5000.

- 3 Select **Append showpage after EPS file to add a 'showpage' PostScript language command at the end of the print job**.

NOTE: Some applications omit this necessary PostScript language command when they generate EPS files. Select this option when printing EPS files generated by these applications. If you select this option unnecessarily, extra blank pages may print.

- 4 Click **Browse** or **type the location of the file on your hard disk to download**.



Your file should already have the appropriate print options, and include (embed) any necessary fonts that are not resident on your print device.

- 5 Click **Download**.

Installer

The Installer WebTool allows you to download installers (for drivers, PPDs, and other printer files) directly from the Fiery EXP6000/EXP5000.

TO DOWNLOAD PRINTER DRIVERS OR USER DOCUMENTATION FILES WITH THE INSTALLER WEBTOOL

- 1 Click **Installer** on the **WebTools** home page.
- 2 Below the name of your operating system, click the name of the item that you want to install.
- 3 Follow the on-screen instructions to install user software or user documentation.

4 For installation of printer drivers, continue with the following instructions.

A dialog box appears, prompting you to save the file to the location you choose.

For Windows computers, a dialog box appears, offering you the choice of running the program across the Internet or intranet or saving it to disk.

For Mac OS computers, a folder named Printer Driver is downloaded to the desktop in a BinHex-encoded, compressed format. If your Internet browser is equipped with an expander utility, such as StuffIt Expander, the folder decodes and decompresses automatically.

5 For Windows computers, browse to the location where you want to save the Prntdrv.exe and click Save.

For Mac OS computers, if the Printer Driver folder did not automatically decode and decompress, start the utility that performs that function.

6 For Windows computers, double-click the Prntdrv.exe file, browse to the location where you want to install the folder, and click Next.

The folder is installed to the location you specified.

7 Install the appropriate printer driver for your operating system.

For more information, see *Printing from Windows* or *Printing from Mac OS*.

Software Updates

The Software Updates link connects you to another web page, which allows you to download system software updates for the Fiery EXP6000/EXP5000.

INDEX

A

Adobe Acrobat 34
 Adobe Photoshop 53
 Align Trays 19

C

chapter definition for jobs 24
 configuring 62
 Command WorkStation, Macintosh
 Edition 39
 Command WorkStation, Windows
 Edition 15
 Downloader 46
 server 65
 WebTools 62
 conventions 8
 cover media 25
 Creo VPS files 44

D

demoting jobs 21
 device name 47
 Direct connection 52, 55
 Domain Name Server (DNS) name 15, 38, 46
 dongle 33
 downloading
 files 51, 65
 fonts 51, 55
 jobs 51
 drag-and-drop printing 58

E

EFI ImageViewer 29
 Enfocus PitStop plug-in 34
 EPS (Encapsulated PostScript) files 44, 53, 65

F

Fiery Graphic Arts Package, Premium Edition
 file format filters 60
 ImageViewer 29
 file format filters 60

font list

displaying 50, 57
 printing 50, 57

fonts

Adobe Type 1 56
 downloading and managing 52
 installer for Mac OS 12
 installing 12
 PostScript 56
 printer fonts 12, 56
 printer fonts on server 57
 screen fonts 12, 56
 substitution with PDF files 56
 full-screen preview 29

G

group printing 20

I

icons, in documentation 8
 ImageViewer 29
 imposing jobs 32
 imposition layouts 32
 Insert Tabs 27
 inserting tabs 27
 Installer WebTool 65
 installing
 Acrobat 34
 Command WorkStation, Macintosh
 Edition 37
 Command WorkStation, Windows
 Edition 14
 Hot Folders 59
 Impose 33
 PitStop 34
 screen and printer fonts 12, 56

J

Java 14, 62
 Java JRE 10
 job queue, reordering 21

jobs

- chapter definitions 24
- cover media 25
- downloading 51
- mixed media definitions 23
- rush printing 22
- scheduling 22
- VDP 32

L

LaserWriter printer, fonts installed on 56

M

- Mac OS
 - fonts 12, 56
- Mac OS Runtime for Java 11
- media definitions 23
- member printing 20
- Mixed Media 23
- MRJ 11

P

- paper definitions 23
- PDF files 52
 - downloading 44
 - font substitution 56
- Photoshop 53
- PitStop plug-in 34
- PostScript files
 - downloading 44
- PostScript printer driver
 - installing using WebTools 65
- preview window 29
- printer fonts 12, 56
- printing
 - font list 50, 57
 - frequently used print options 58
- Printing Groups 20
- Prntdrv.exe file 66
- promoting jobs 21

R

- remote setup 65
- Reorder Jobs 21
- Runtime for Java 11
- Rush Printing 22

S

- Schedule Printing 22
- screen fonts 12, 56
- server setup 65
- software protection key 33
- Software Updates WebTool 66
- Status WebTool 64
- Sun Java JRE 10
- system software updates 66

T

- tab insertion 27
- tab media 27
- TCP/IP 15, 38, 46
- terminology 8
- TIFF files 44, 52
- transfer functions 53
- tray alignment 19
- troubleshooting
 - Command WorkStation,
Macintosh Edition 42
 - Command WorkStation,
Windows Edition 30

U

updating system software 66

V

- variable data printing, *see* VDP jobs
- VDP jobs
 - downloading 44
 - imposing 32
- VPS files 44

W

- WebDownloader 65
- WebLink 64
- WebSetup 65
- WebTools 62
 - home page 63
 - Installer 65
 - Software Updates 66
 - Status 64
 - WebDownloader 65
 - WebLink 64
 - WebSetup 65