

PHASER® 750  
LASER PRINTER  
**SETUP GUIDE**

### 1 Placement

Place in well ventilated area

43 kg  
94 lbs.

1.1

1.2

Front

Lower Tray Assembly (option)

### 2 Remove Tape

### 3 Prepare Imaging Unit

TIGHTEN

LOOSEN

### 4 Unpack All Toner

Remove cover

### 5 Load Toner

5.1

5.2

Door open 2 minutes maximum

### 10 Load Software

PHASER 750 LASER PRINTER

Windows:  
CD-ROM is auto-running, or  
run *start.exe*

Macintosh:  
Double-click *Start Me First*

### 9 Turn On Printer

9.1

9.2

Ready

For network installation,  
see Software CD-ROM  
or [tektronix.com/Color\\_Printers/support/](http://tektronix.com/Color_Printers/support/)

### 8 Connect Cables

Token Ring Network Card (option)

Order A/B USB cable separately

USB connection: Macintosh or PC

USB

Ethernet

Parallel

Direct Ethernet: Macintosh or PC

Order hub and cables separately

Parallel: PC only

Order cable separately

Use provided adapter, if necessary

### 7 Install Trays

Multi-purpose Tray  
Glossy paper, transparency or laser paper

With Lower Tray Assembly (option)  
Duplex unit or laser paper tray  
Transparency tray or laser paper tray  
Laser paper tray only

### 6 Load Laser Paper

6.1

6.2 Remove packing material

6.3

6.4

6.5