What is the Xerox DocuPrint Enterprise Printing System?

Your Xerox DocuPrint Enterprise Printing System is a highspeed production printer with many features you can use to enhance your documents. You can set up your job to:

- Use up to six different paper stocks in the same job (depending on the number of paper trays in your printer).
- Use a wide variety of stock sizes, types, and weights:
 - From 8 x 10" / 203 x 254 mm to 11 x 17" / A3
 - 7 x 10" / 178 x 254 mm with small paper kit installed
 - Ordered stock, preprinted stock, tab stock
- Include different sizes and types of paper in the same job.
- Take advantage of high-quality 600 dpi output with Enhanced Resolution Imaging, where even fonts as small as 3 points are sharp and crisp.
- Print 1-sided, 2-sided, or head-to-toe 2-sided.
- Use resident PostScript and PCL fonts as well as downloaded fonts.

Types of files you can print

The types of files you can submit from a workstation for printing on the Xerox DocuPrint Enterprise Printing System are:

- PostScript 3.0
- PCL 5e
- TIFF
- PDF
- ASCII

How to create print files

Application files are not in a print format like PostScript or PCL 5e, but are in the format of the creation application (for example, database or publishing software). To print your job, your software must generate a file that the printer can process. There are two ways to do this.

· Create a print file, then submit it.

From the application, use a PostScript or PCL driver to print to file; the result is referred to as a "print file."

Submit the print file, for example, with Ipr or FreeFlow Print Manager.

Print directly from the application.

Print from the application using a driver that allows you to print to a Xerox DocuPrint Enterprise Printing System. This procedure transparently generates a print file and submits it to the Xerox DocuPrint Enterprise Printing System.

You might want to use a separate process to create a print file (instead of printing from your application) if you want to create a print file that you can submit repeatedly. Or you may need to give the print file to someone else for printing, and that person may not have the original application software.

To create a print file and submit it to the printer, you must set up your workstation's printing facility. Consult your application documentation or system administrator.

Submitting a job

There are several methods for submitting a job, depending on the type of workstation you have. Xerox provides customized print drivers for your specific printer. This software is usually shipped with the printer.

When you submit the job, you specify the way you want the job to print, for example, 50 copies, two-sided, on blue drilled paper. The set of parameters you specify is referred to as a "job ticket."

How do you know what paper is loaded?

If the type of paper you request for your job is not loaded in the printer when you send your job, the job will wait until that paper is available. The operator will check for jobs that are waiting for a particular stock. After the required stock is loaded, the job will print.

Using a queue

When you submit a job, you submit it to a particular queue. Your organization can use queues to manage jobs. A queue can be used to:

- Give operators control over when to accept jobs from the network.
- Give operators control over when to release jobs to the printer.
- Apply default parameters (like 1- or 2-sided printing).
- · Override parameters you specified for your job.

The queue override means that the property defined in the queue will be applied to your job, even if you specified a different value for the property. For example, if the job has a property that specifies 1-sided printing, and the queue specifies 2-sided printing, and the override is enabled, then the job will print 2-sided.

In short, the way a queue is defined can affect how and when the job prints. You should be aware of what queues are available for your printer, and what parameters they use.

What determines how your job prints?

There are several factors that can affect how your job prints.

- The method you use to create it, that is, the driver used to create the PostScript or PCL print file.
- The way you send it, for example, if you use a driver or FreeFlow Print Manager.
- The printing parameters you specify (type of paper, number of copies, and so on) when you submit the job.
- The settings for the queue you send the job to, and whether or not overrides are used.
- Whether the operator changes the job's properties.
- Whether the type of paper defined for a particular tray is actually in that tray. Consider an example. You want your job to print on white paper and you specify that when you send the job. If there is a paper tray defined as having white paper, but there is really blue paper in the tray, the job will print on the blue paper because the system "thinks" it is white.

Saving a job

When you submit your job, you can request that the job be saved at the controller. This means that you or the operator may use the Print Services capability to print this job on demand. A saved job is held in print-ready format, and the initial job ticket is also saved for you to use as needed. You may also use a saved job as a form over which you may merge variable data.

The procedure for saving the job depends on the job submission method you use. A queue can also be configured to save jobs sent to it.

Using a saved file

Print Services allows you to reprint a job that has been saved to the controller. When the job is saved, its job ticket is saved as well. You may use the parameters in the job ticket, or change them as needed.

Xerox DocuPrint 100/115/135/155/180 EPS

User Job Submission Quick Reference Card

Refer to this card when submitting documents from a workstation to be printed on the Xerox DocuPrint 100/115/135/155/180 Enterprise Printing System. This card helps you to understand and take advantage of the capabilities of your printer.

THE DOCUMENT COMPANY XEROX

Version 4.1 September 2004 701P42239