








Introduction

The following table lists the WorkCentre's lower portion Control Panel keys. Refer to the Table of Contents to locate specific function information.

Item	Description	Function
11	<p><i>Menu</i></p> 	The Menu key is used to access menu items listed in the menu map which are not available from the direct access keys. The Menu key is also used as a navigation key for scrolling up a menu list.
12		Right navigation key used for going to the next level of menus of the highlighted item. Also used when you enter names for positioning the cursor for character delete or insert.
13	<p><i>Enter</i></p> 	Used to select the displayed menu item, to start a communication, or to accept name and number entries.
14	<p><i>Resolution</i></p> 	Used to set the resolution for copying, scanning, or faxing. The following settings are available: Standard (no LED lit, fax only), Fine, Superfine, Photo Fine and Photo Superfine.
15	<p><i>Contrast</i></p> 	Sets the contrast of the printout to Normal (no LED lit), Lighten, or Darken. This is a scanner setting affecting send and copy.
16	<p><i>Copy</i></p> 	Used to copy documents.
17	<p><i>Manual Dial</i></p> 	Used for interactive dialing. Digits are dialed as the key is pressed. The line monitor automatically turns on.