

Reports

The following information is printed on the Relay Destination Confirmation Report:

Item	Description
Job number	Job Number of transmission.
Date	Date and time that the job was accepted.
Document pages	Number of pages of memory input.
From	Originating Station telephone number.
Start time	Time when the transmission started.
End time	Time when the transmission ended (the time when a Resend Stored Fax transmission is designated).
Successful	List of Speed Dial or Group numbers where the transmission was sent.
Unsuccessful	List of Speed Dial or Group numbers where an error occurred. Sent Pages - The number of pages sent.

Relay Destination Report

12. Select the Relay Destination Confirmation Report print option:

Relay destination
1. Always
2. On error
3. Off

To automatically print a report after the Relay, press **1**.

To automatically print a report when an error occurs, press **2**.

To disable the report feature, press **3**, then go to step 14.

Reports

13. For Always or On Error reports you can have the WorkCentre print the first page* of the fax on the Relay Destination Report.

Show first fax page
1. On
2. Off

To print the first fax page, press **1**.

To print the report without the first fax page press **2**.

14. Press **Stop** to return to the Standby Mode.

* Not allowed in all markets.