

Transmitting Documents

ECM Disable

Once the Error Correction Mode Default Setting is set to "ON", this feature allows you to disable the ECM mode for a single transmission. Once that transmission is complete, the default status is regained.

Note: *ECM must be set to On when the optional 33.6K BPS Modem is installed. Disabling ECM also turns the 33.6K BPS Modem off. If the ECM Default setting is set to "OFF", the ECM Disable feature is not available. (See Chapter 4, "Error Correct — ECM Default Setting".)*

To set the ECM feature:

1. Load the document face down in the Document Tray.
2. Select the desired **Resolution** and **Contrast**.
3. Press:



Error correct — ECM
1. On
2. Off

4. Select the ECM option:

To send the document using ECM, press **1**.

To disable the ECM Mode for this transmission, press **2**.

Free Memory 100%
Enter fax number

5. Press **Menu** to select additional fax options, or using one of the dialing methods, enter the fax number, then press **Enter** if necessary.

The document is sent and the machine returns to the Standby Mode.