

## Speed Dialing


---

Once you assigned a destination fax number as a Speed Dialing number, you can dial your destination by entering the Speed Dial number (001-999).

To use this function, the Speed Dial number must be programmed in the Speed Dial Phonebook (see Chapter 4, "Presetting Speed Dial Numbers").

To dial a remote station using a Speed Dial number:

1. Load the document face down in the Document Tray.



05-01-97 Thu15:47  
Ready  
Free Memory 100%  
Dial or press Copy

2. Select the desired **Resolution** and **Contrast**.
3. Press the **Speed Dial** key.

*Speed Dial*



4. Prompt for a Phonebook, select **1** for "Speed dial".

