

Relay Station Report

10. Select the Relay Station Confirmation Report print option:

Relay station
1. Always
2. On error
3. Off

To automatically print a report after a Relay, press **1**.

To automatically print a report when an error occurs,
press **2**.

To disable the report feature, press **3**, then go to step 12.

11. For Always or On Error reports you can have the WorkCentre print the first page* of the fax on the Relay Station Report.

Show first fax page
1. On
2. Off

To print the first fax page, press **1**.

To print the report without the first fax page, press **2**.

* Not allowed in all markets.