

Dialing Methods

3. When you hear the fax tone, press **Start**.

The machine dials the number. If the connection is confirmed the document is sent. If the line is still busy, the job remains in the pending job list.

Redial Pending Jobs*

This function enables you to transmit a document after selecting it from all pending jobs reserved in memory waiting to be redialed.

To redial a Pending Job:

1. With the handset* placed on hook, press **Redial/Pause**.

Redial/Pause



Redial last number
[Enter] to start
Previous [↑]
Next [↓]

Note: *If no key is pressed within 5 seconds, the first reserved job is displayed.*

2. Press the  and  arrow keys to view each reserved job waiting to be redialed.
3. When the required job is displayed, press **Enter**.

The machine dials the number. If the connection is confirmed the document is sent. If the line is still busy, the job remains in the pending job list.

*Not allowed in all markets.