

Enter password

Password (20 max):



7. Using the Numeric Keypad, enter the password you want to assign to this box, then press **Enter**.
8. The display will return to the mailbox setup screen. You may add additional mailboxes by selecting **2**, or you can return to the standby mode by pressing **1** or **Stop**.

Deleting an ITU-T Mailbox

Before documents can be stored, the mailbox number must be setup in your mailbox station.

Hint: To print a list of all documents in your ITU-T mailboxes, press:

Menu



2

4

(See Chapter 12 "Reports".)

To delete a mailbox:

1. Open the Access Cover and press:

Mailbox
ITU-T



3

Mailbox setup

1. Done

2. Mailbox setup

3. Mailbox delete

2. Select the Mailbox option.

To return to the Standby Mode, press **1**.

To delete a mailbox, press **3**.