

## Print Resolution Setting

---

When the machine is powered on, the maximum Print Resolution is automatically selected according to the size of memory installed.

The Print Resolution can be changed to improve print quality, but, the size of image storing memory will decrease. Refer to Chapter 17, "Image Memory".

**Note:** \* For a WorkCentre 635 without optional memory the resolution is fixed at Fine (no selection are available).

To change the Print Resolution:

1. Press:



### Print Resolution

1. Fine
2. Extra fine\*
3. Super fine\*\*

2. Select the Print Resolution Option:

To select Fine, press **1**.

To select Extra fine, press **2**.

To select Super fine, press **3**.

3. The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.

**Note:** \* Available only when 2MB or more optional memory is installed.  
\*\* Available only when 4MB optional memory is installed.