Send then Poll

This feature performs two operations, transmit and poll, in a single operation. If the remote machine has a document set to be polled, the polling document is received after your document is sent, during the same call (this is a one time procedure).

To set the Send then Poll feature:

1. Load the document face down in the Document Tray.

2. Select the desired **Resolution** and **Contrast**.

3. Press:

    Menu
    ▲ (1) (3)

Send then poll
1. On
2. Off

4. Select the Send then Poll option:

    To enable the Send then Poll feature, press (**1**) .

    To disable the Send then Poll feature, press (**2**) , then go to step 6.

Send then poll
Add security code?
1. Yes
2. No

5. Select the Security option:

   To enter a Security Code, press (**1**) , then use the Numeric Keypad to enter a 4-digit code, and press ***Enter***.

Free Memory	**100%**
Enter fax number	

   If you do not wish to enter a security code, press (**2**) .

6. Press ***Menu*** to select additional fax options, or using one of the dialing methods, enter the fax number, then press ***Enter*** if necessary.

Free Memory	**100%**
Enter fax number	

   The document is sent. If this feature is enabled, the document set to poll is received, then the machine returns to the Standby Mode.