

Maintaining the Machine

Cleaning the Machine

Cleaning the Cabinet and Ozone Filter

Wipe the machine with a damp cloth to remove dust and fingerprints. Use water to dampen the cloth. Do not use chemicals for cleaning, as this can cause discoloration or damage to the finish of the machine.

Use a vacuum cleaner or brush to remove dust from the vents and the Ozone Filter (see figure). Refer to “Replacing the Ozone Filter” in the previous section to replace the Ozone Filter.

