

3 Getting Started

This chapter contains step-by-step procedures to program the machine settings and set up the most commonly used facsimile features. To get you started quickly, basic steps to send, receive, and copy a document are also provided.

For additional setup functions, refer to the appropriate chapter.

Setting the Machine Language

The WorkCentre is capable of displaying and printing in various languages.

Note: Available Languages may vary depending on your location. If not available, "Not Allowed Now" will display.

To change the machine language:

1. Press:



1. XXXXX
2. XXXXX
3. XXXXX
4. XXXXX

2. Use the Numeric Keypad to select the desired language, then press **Enter**.

The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.