

Note: *If using a security code for this poll operation, all machines must be set with the same code.*

8. If required, enter a 4-digit Security Code, then press **Enter**.

Continuous Polling starts when the machine clock reaches the start time.

Deleting Continuous Poll Jobs

To modify the continuous poll operation, you must delete and reenter the information.

To delete a Continuous Poll Job:

1. Open the Access Cover and press:

Polling



Already assigned

1. Delete

2. Retain

2. To delete the Continuous Poll Job, press **1**.

The Continuous Poll Job is deleted and the machine returns to the Standby Mode.